


Cod. 10548


Klicker




● I ricambi indicati in rosso non sono vendibili separatamente
The spare parts written in red are not sold separately
Die rot geschriebenen Teile nicht separat verkauft
Las partes escritas en rojo no se venden por separado
Les pieces detachees en rouge ne sont pa vendu separement




Pos. 026 10597 Complete gearbox - Slow
10795 Complete gearbox - Fast




Pos. 042




Pos. 074




Pos. 058



Pos. 059



Pos. 062



* Ricambi consigliati / Recommended spare parts
Empfohlene Ersatzteile /Repuestos recomendados / Pièces de rechange recommandées

Cod.	Pos.	€	Cod.	Pos.	€	Cod.	Pos.	€	Cod.	Pos.	€	Cod.	Pos.	€
10593	01		3010966	11		3010984	30 *		30618	47		3010181	64	
10598	02		20290	12		30208	31		20112	48		30785	64a	
3010964	2a *		3010967	13		20295	32		30734	48a		30233	68	
3010965	2c		3010466	13a		20294	33		30878	50		3010969	69	
30684	3		30559	14		30185	34		30771	51		3010971	69a	
30685	4 *		30753	15		30102	35		30578	52		30965	70	
30686	5		30628	16		30103	35a		30772	53		3010648	71	
30077	6		30187	16a		30566	36 *		30511	53a		3010972	72	
30687	7		10293	017		30211	37		30773	54		3010358	73	
30688	8		30190	18		3010968	38		30879	55		10596	074	
30689	8a		10501	019		10592	039 *		3010382	56		3010359	74	
30690	8b		10255	022		3010444	41		30839	56a		3010360	75	
30866	9		30758	23		10591	042 *		10188	058		3010362	76	
30160	9a		30748	24		301083	42a		10366	059				
30108	9b		10597	026 *		30093	43		30778	59a				
10394	010		30738	27		30094	44		301093	61				
10404	010a		30613	28		30767	45		10295	062				
30114	10c		30678	29		30959	46		30783	63				